


Dynamic[®] TROLLEY


INSTRUCTIONS



Parts List

- A Handle bars
- B Main frame
- C Hinged side bars
- D Pneumatic wheels x 2
- E Back axle bar
- F Washers x 2
- G Figure of 8/lynch pins x 2





NOTE:
Wheel valve should be fitted
on inside of trolley

